



**1**

Align the device keyboard under the bottom case's front clips on both sides.



**2**

Pop on the side clips.




**3**

Carefully press the rear corner clips to snap onto the keyboard.




**4**

Align the device screen under the top case's side clips on both sides.




**5**

Slide the top case down **evenly (leveled)**, to secure the screen behind the side clips, until the device reaches the case's top edge.



**6**

Close the case and press on the clips located on the rear of the top case. Make sure the clips are securely attached.




**CRITICAL!**  
FOLLOW STEPS 1 AND 2 IN ORDER

Failure to do so may result in  
damage to the device.




**1**

Unhook the rear clips to release the bottom of the top case from the device.



**2**

Start sliding the top case off by pushing up with your fingers on the bottom corners.




**3**

Gently push the rear clips down to unhook from the device.



**4**

Push the left and right side clips down past the device, one side at a time, to release it from the bottom case.



**The PC case is recyclable if the feet on the bottom case are removed!**

